# Bob's Card Models

www.bobscardmodels.altervista.org and www.zealot.com [Resources]



**Eurocopter EC145T2** Scale: 1:72

The **Eurocopter Group** is a global helicopter manufacturing and support company. It is the largest in the industry in terms of revenues and turbine helicopter deliveries. Its head office is located in France at Marignane (Marseille International Airport).

The EC145T2T, is the newest 4-ton class twin engine, multi-purpose helicopter in the product range of Eurocopter, and has seen more than 800 deliveries worldwide and has accumulated over 3 million flight hours

The livery chosen is that of France's Securité Civile air rescue and and fire-fighting organisation, based at Marignane airport near Marseilles, France.

## Specifications (Wikipedia)

## **General characteristics**

Crew: 1 or 2 (pilots)
Capacity: 9 passengers

Length: 13.03 m
Rotor diameter: 11.0 m
Height: 3.45 m
Empty weight: 1,792 kg
Max takeoff weight: 3.585 kg


Powerplant: 2 × Turboméca Arrius Main

## **Performance**

Max. speed: 268 km/h
Cruising speed: 246 km/h
Range: 680 km
Service ceiling: 5,240 m
Rate of climb: 8,1 m/s

\_\_\_\_\_

## **Building Instructions**



Print Sheets 1 and 2 on between 160 and 230g card, except Instructions and Sheet 3 which should be printed on 80 - 90g Paper.

Always carefully fit parts together before gluing, and make minor adjustments if necessary.

Bright Green areas must be cut out, BUT only after gluing any folds. The Instructions will tell you when! Although the model is relatively small, bulkheads have also been used to keep the correct cross-sectional form of the fuselage; therefore, they don't have to be glued all around, but rather tacked in place (do not tack on the green areas, which will anyway be cut off). The bulkheads should not be pressed in firmly, but loosely, otherwise after gluing, an unwanted ribbing effect is seen on the outside.

#### NB:


Parts 1, 2 and 3: These should be cut oversize then bent/folded along the fold lines, then cut to size. The parts should be assembled in the following order:


- 1. 1-2, 2-3, 3-4L, 3-4R
- 2. In nose cone, glue a 3-5gm weight.
- 3. On 5, close/glue tab 'a'.
- 4. Glue 5-4L/4R.
- 5. Close/glue tab 'b' on 5.
- 6. Insert/glue Bulkhead A.
- 7. Close/glue 6.
- 8. 7-6, 6/7-5, 8-7.
- 9. Close/glue 9, 10.
- 10. Insert B in 9 (1-2mm countersunk)
- 11. 9-10.
- 12. 12-9
- 13. 11-14: NOTE: Small tabs on 11 must be folded **INTO** the tube; To aid in inserting 11 through the front of 14, first loosely insert a piece of paper from the rear of 14 to hold down the tabs, insert 11, remove paper insert.
- 14. 11/14-10
- 15. 15A and 15B -11
- 16. Glue 16 in place
- 17. Glue 2 halves of 17 together, previously bending the 4 end fins 90° so that coloured sides point INWARDS, then glue on fins 18A and 18B. Glue central fin 19 in place. Insert in slit at end of 14, and glue in place.
- 18. Assemble and mount rear propeller.
- 19. Assemble main Prop with parts 21-22, and cap with 23. Glue onto cocktail stick, and cut to length.
- 20. Assemble undercarriage and skids, then glue in place.




















23





# Sheet 2

SecCivilcopter



# Print on 80-90g paper

SecCivilcopter